



NOTES

- ① Set the ALARM float 24" below the invert, or equal to 20 Minutes of flow.
- ② Set the OFF float to top of pump

DATE:	REVISED:	CITY OF WASILLA	PUMP VAULT	SCALE:
DRAWN BY:	1/23/12			NONE
CHECKED BY:	Utility Maint.			SHEET
				1 OF 1
				FIGURE:
				430 A